

Talia Suite

Installation Instructions

1. Carefully unpack the Suite and the Dimplex 600 Chassis fire. Remove the protective feet from the suite base unit **(please be careful NOT to drag the base when these are removed)**
2. Slide the fire from the rear into the slot in the base of the Suite ensuring that the rear of the fire sits on the rear hanger correctly.
3. Position the Suite base complete with fire into the final required location (no fixing is required)
4. Fix the fire wings (larger pair that have small magnets fitted and marked left and right) into the correct position either side of the fire.
5. Fix the side wings into position (not handed). These are made to be normally freestanding. If user wishes to fit or stick these to the fire wings this would be carried out at the users own risk and would not be covered by the manufactures warranty if damaged.
6. Carefully fit top onto the fire and fix back to the wall. This can be done by using the hidden brackets (supplied). Other options (Not supplied) of fixing this top include brass mirror brackets or a suitable Grab adhesive (not supplied).
7. Complete the setting up of the Dimplex Chassis 600 fire as per the installation instructions supplied with the fire.