

Contact Details

Please note that some of the contact details on this PDF document may not be current.

Please use the following details if you need to contact us:

Telephone: 0844 879 3588

Email: customer.services@gdcgroup.co.uk

The customer support section of our website also features a wide range of information which may be of use to you and is available 24 hours a day. It includes:

- Operating and installation instructions
- Easy 'How to use' guides for storage heaters
- Service and repairs
- Where to buy our products
- Literature downloads
- Heating requirement calculator

Visit - www.dimplex.co.uk/support

Quick Start Guide




Apollo Electronic Radiant Panel Heat with Towel Rail

QS001

This guide is for quick reference only. Refer to the appropriate installation and operating instructions for further information

Apollo Heater




General

- Use the heater in comfort mode * when the room is
- Use the heater in set back (background) mode \(\sqrt{w}\) when the room is unoccupied. It is more energy efficient to do this than switch the heater off.
- Use the heater in frost protection mode w if you are away for long periods of time.

Heater controls

- (A) Function selector: see table below for functions available
- (B) Function display: will illuminate to show which function has been selected with the function selector
- (C) **Thermostat:** set the thermostat control to the appropriate position to give comfort level required. Heater will switch on and off as necessary, and a higher setting will make the
- (D) Thermostat indicator: will illuminate to show when heater is delivering heat
- Cover opening tab (E)



- A Function Selection
- (B) Function Display (C) Thermostat
- (D) Thermostat Indicator
- (E) Cover Opening Tab

Function selector table

Symbol	Function	Description
*	Comfort	Heater will maintain the temperature set on the thermostat dial
C	Background (setback)	Heater will maintain a lower temperature level for background heating (preset to -3.5°C)
0	Off	Heater will not function
Ф	Programme	Heater will be controlled by a programming device

*Note: If the programme function is selected but no programming device is being used, the heater will function in comfort mode.