
CDimplex

Volterra Opti-V Stove



Model: VLT-OV Instructions

UK



IMPORTANT: THESE INSTRUCTIONS SHOULD BE READ CAREFULLY AND RETAINED FOR FUTURE REFERENCE

Introduction

Thank you for chosing this Dimplex Opti-V stove. Please read information guide carefully to be able to safely install, use and maintain your product.

Important Safety Advice

When using electrical appliances, basic precautions should be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

If the appliance is damaged, check immediately with the supplier before installation and operation.

Do not use this appliance in the immediate surroundings of a bath, shower or swimming pool.

Means for disconnection must be incorporated in the fixed wiring in accordance with the wiring regulations.

Do not use outdoors.

In the event of a fault disconnect the appliance from mains supply.

Switch off the appliance when not required for long periods. If the supply cord is damaged, it must be replaced by a special cord or assembly available from the manufacturer or its service agent.

Warning - No naked flame sources, such as candles, should be placed on this apparatus.

Warning - The appliance shall not be exposed to dripping or splashing and that no objects filled with liquid, such as vases, shall be placed on the apparatus.

Warning - this appliance is of Class I construction and must be connected to a mains outlet with protective earthing connection.

Electrical

WARNING - THIS APPLIANCE MUST BE EARTHED

Do not switch the appliance on until properly installed. Please read all the safety warnings and operating instructions.

General

Unpack the appliance carefully and retain the packaging for possible further use, in the event of moving or returning the appliance to the supplier.

Contents of Carton

- Opti-V Stove Model VLT-OV
- Remote control
- Supply cord

Product Features

Volume Control
Remote or Manual operation
Red light indication of standby mode

Installation Warning.

Do not connect the appliance until the instruction leaflet is read fully.

Connect the supply cord(kettle type connection) to the socket at the back of the appliance and plug opposite end to mains supply.

Operation - remote control: -

The appliance by default is in standby mode, indicated by a red light at the front of the appliance.

To activate the remote control, remove the battery clear, plastic strip, which is used to ensure the remote is fully charged before use - see **Fig.2**.

To operate, aim the remote control to the front of the appliance. Press the standby button (**b**) on the remote control (see **Fig. 2**).

The fuelbed will light up and after approximately 7 seconds the flame will appear.

Note: The user may notice a blank screen for approximately 3 seconds, every 30 minutes. This is normal and should not be a cause for concern.

The audio volume may be adjusted up or down by pressing the volume control buttons (+ and -).

To create the shadow effect on floor, press the shadow 'light on' button (\circlearrowleft) .

To turn the effect off, press the shadow 'light off' button(⊗).

For battery replacment refer to the embossed diagram on the back of the remote control.

NOTE - Use Lithium batteries only - CR2025

Attention should be drawn to the environmental aspects of battery disposal.

Manual Control Operation: -

The manual controls are located at the back(top) of the appliance.(see Fig. 3).

Maintenance

WARNING – ALWAYS DISCONNECT FROM THE POWER SUPPLY BEFORE ATTEMPTING ANY MAINTENANCE.

Techical Information:

100-240V ~ 50/60Hz

Power consumption 28W Stand-by Power 1W

Cleaning

For general cleaning use a soft clean duster – never use abrasive cleaners.

Recycling


For electrical products sold within the European Community.


At the end of the electrical products useful life it should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice in your country.

After Sales Service

Should you require after sales service or should you need to purchase any spares, please contact the retailer from whom the appliance was purchased.

Please retain your receipt for proof of purchase.







The product complies with the European Safety Standards EN60065 and the European Standard Electromagnetic Compatibility (EMC) EN55014-1 & EN55014-2, EN6100-3-2 and EN6100-3-3 These cover the essential requirements of EEC Directives 2006/95/EC and 2004/108/EC Patents pending Application No.: GB 1509765.2

 Dimplex
 TEL: 0844 879 3588

 Millbrook House
 FAX: 0844 879 3583

Grange Drive WEBSITE: www.dimplex.co.uk

Hedge End Republic of Ireland Tel. 01 8424833

Southampton

Hampshire. SO30 2DF

[c] GDC Group Ltd,

All rights reserved. Material contained in this publication may not be reproduced in whole or in part, without prior permission in writing of Dimplex.

A division of GDC Group Ltd,