






<http://help.nobo.no>



Automatisk søk / Automatic search / Автоматический поиск



Advarsel! Bruk korrekt batteritype for å unngå eksplosjonsfare. Brukte batterier skal leveres som miljøavfall.

Caution! Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.


Внимание! Опасность взрыва, если батарея заменена неправильным типом. Использованные батареи выбросить в соответствии с инструкциями.



CR2032, 3V



RF 868,4 MHz
≤10 mW



NOBO

SWITCH SW4

Trådløst bryterpanel
Wireless switch panel
Беспроводная панель
переключателей

Brukerveiledning
User guide
Инструкция





§



CE



WEEE

SAMSVARERKLÆRING (DoC).

Glen Dimplex Nordic AS erklærer herved at utstyret som er beskrevet i denne anvisningen (NOBØSWITCH SW4) oppfyller alle vesentlige krav og andre relevante bestemmelser i EU- direktiv 2014/53/EU. Ved behov for kopi av DoC kan forespørsel sendes til: email@glendimplex.no

DECLARATION OF CONFORMITY (DoC).

Glen Dimplex Nordic AS declares that the equipment described in this user guide (NOBØSWITCH SW4), is in compliance with the essential requirements and other relevant provisions of EU Directive 2014/53/EU. If you require a copy of the original signed DoC, please send an E-mail to: email@glendimplex.no



GlenDimplex
NORDIC

Wessels veg 63, 7502 Stjørdal, NORWAY
www.glendimplex.no
email@glendimplex.no

