



# **Dimplex**



CXD2000H




CXD2000V




08/19367/0 Issue 0

---






**CE** The product complies with the European Safety Standards EN60335-2-30 and the European Standard Electromagnetic Compatibility (EMC) EN55014, EN60555-2 and EN60555-3 which cover the essential requirements of EEC Directives 73/23 and 89/336

**1**

CXD2000V



CXD2000H

**2****3****4**

THESE INSTRUCTIONS SHOULD BE READ CAREFULLY AND RETAINED FOR FUTURE REFERENCE

### Important Safety Advice

**Because the Dimplex Ceramic Radiant Heater contains no moving parts little maintenance is required. Before undertaking any maintenance work on the heater due attention must be paid to the following:**

**This heater is designed to be horizontally wall mounted only, it must not be ceiling mounted.**

**Always ensure a safe mounting height, at or above a minimum height of 1.8 metres from ground level, so that the heater can not be touched when in operation.**

**The heater must be wall mounted level  $\pm 5^\circ$  to the horizontal.**

**Do not locate the heater immediately above or below a fixed socket outlet or connection box.**

**Always disconnect the heater from the electricity supply before attempting to work on or near it.**

**Always ensure a safe means of access using an access tower or properly supported ladder.**

**Do not cover the heater.**

**Keep combustible materials away from the heater.**

**Do not position patio furniture, sunshades, awnings and other combustible materials too close to the heater.**

**Do not use heater if the elements are broken - as injury may occur.**

**Allow adequate time (minimum of 30 mins.) for the elements and body casing to cool before attempting to work on the heater.**

**Wiring between the heater and the spur outlet or isolation switch must be in a heat resisting cable (e.g. polychloroprene).**

**Note: Provide sufficient slack to the cable to allow for angular adjustment of the body.**

**The supply cord should be regularly examined for signs of damage and the appliance is not to be used if the cord is damaged.**

### General

Your Dimplex Ceramic Radiant Heater uses ceramic elements which produce a high proportion of their output in the long-wave infra-red. This provides a high comfort factor – similar to the natural energy from the sun.

### Electrical

**The installation of this appliance should be carried out by a competent electrician and be in accordance with the current IEE wiring regulations and any local or insurance regulations.**

The CXD2000H & CXD2000V are designed for use on a 230-240V AC single phase supply.

An all-pole isolating switch with a minimum separation of 3mm in each pole must be fitted to facilitate isolation. This switch must either be positioned inside a building or have an IP rating against water ingress suitable for external installation.

The appliance must be supplied through a residual current device (RCD) having a rated residual operating current not exceeding 30mA.

The appliance must be connected to a socket-outlet having an earthing contact.

**Note :** Always ensure the cable grip is tightened.

### Installation

Heaters are supplied with an integral wall bracket which may be fixed through the mounting holes to any suitable structure. The bracket allows the heater to be inclined at the required angle. The recommended fixing height to the centre line of the bracket is 2.0m from ground level - see **Fig. 2**.

The integral wall fixing bracket may be removed by fully unscrewing to facilitate its fixing.

The siting of the heater(s) should be such as to allow an even and uninterrupted distribution of radiation to the area(s) to be heated. Heaters are most effective when the beam angle is inclined down at an angle of between 30° to 45° to the vertical - see **Fig. 2**.

When deciding upon the best location, consideration must be given to the following requirements:

- a. Avoid structures which might vibrate e.g. crane gantries. These could adversely affect element life.
- b. Comfort and safety could be compromised unless the heater is mounted at or above 1.8m from ground level.
- c. Allow a minimum of 500mm minimum clearance between the top of the heater and any horizontal surface - see **Fig. 1**.

### Element Replacement (see Fig. 4)

**WARNING – BEFORE UNDERTAKING THIS TASK ENSURE THE HEATER IS DISCONNECTED FROM THE ELECTRICITY SUPPLY AND LEFT TO COOL FOR A MINIMUM OF 30 MINUTES.**

1. The heater should be taken off the wall.
2. Remove the screws (a) and (b) which hold the control box on the back of the heater.
3. This will allow access to the elements. Remove the retaining clips and spring clips (c) to loosen the elements.
4. Disconnect the elements from their terminal blocks.
5. Remove the screws (d) which hold the back panel.
6. Remove the splash brackets (e) on the elements.
7. Bend the bars on the guard as indicated in **Fig. 3** to remove it.
8. The old element should drop out through the front of the heater, reverse the process when replacing with the new element.

## **Cleaning and User Maintenance**

**WARNING: BEFORE UNDERTAKING CLEANING OR MAINTENANCE WORK ON THE APPLIANCE, DISCONNECT THE ELECTRICITY SUPPLY.**

Since the appliance contains no moving parts little maintenance is required beyond cleaning and element replacement. It is however essential that the heater is not operated with an accumulation of dust or dirt on the element, as this can cause a build up of heat and eventual damage. For this reason the heater must be inspected regularly, depending upon conditions and at least at yearly intervals. Allow adequate time for the element and body casing to cool before attempting to work on the heater - a minimum time of 30 minutes is recommended.

## **After Sales Service**

Your product is guaranteed for one year from the date of purchase.

Within this period, we undertake to repair or exchange this product free of charge (excluding element & subject to availability) provided it has been installed and operated in accordance with these instructions.

Your rights under this guarantee are additional to your statutory rights, which in turn are not affected by this guarantee.

Should you require after sales service you should contact our customer services help desk on 0870 727 0101. It would assist us if you can quote the model number, series, date of purchase, and nature of the fault at the time of your call. The customer services help desk will also be able to advise you should you need to purchase any spares.

Please do not return a faulty product to us in the first instance as this may result in loss or damage and delay in providing you with a satisfactory service.

Please retain your receipt as proof of purchase.

---

Glen Dimplex UK Limited  
Millbrook House  
Grange Drive  
Hedge End  
Southampton  
Hampshire. SO30 2DF

UK customer help line (8.00AM – 6.00PM Mon-Fri; 8.30AM-1.00PM Sat)  
Customer Services: Tel. 0870 7270101  
Fax. 0870 7270102  
e-mail [customer.services@gldimplex.com](mailto:customer.services@gldimplex.com)  
Republic of Ireland Tel. 01 8424833