

Installation and Operating Instructions

08/19538/0 05/08 Issu

Dimplex Air Curtain - Single Phase Conversion Kit
Suitable for use with the CAB10E, CAB15E & DAB10E (Surface & Recessed)

THESE INSTRUCTIONS SHOULD BE READ CAREFULLY AND RETAINED FOR FUTURE REFERENCE.

IMPORTANT SAFETY ADVICE

ENSURE THE APPLIANCE IS EARTHED.

This work should only be carried out by a competent electrician.

Always disconnect the supply before working on the product.

Ensure the supply cables are of adequate current carrying capacity and are protected by a suitable fuse.

Ensure all wiring is fixed clear of all moving parts and

heat sources.
This kit is **not** designed for use with DAB15 models.

The conversion kit consists of:

- 8 x 100mm x 2.5mm tie wraps
- 5 x Moss plastic tie wrap clip
- 1 x Neutral link cable
- 1 x Live link cable

The instructions for the conversion kit should be read in conjunction with the 'Dimplex Air Curtain' Instructions. All 'Safety Advice' to be heeded before fitting this kit.

General

The CAB10E, CAB15E, & DAB10E are primarily designed for 400V~ 3P&N 50Hz operation, however in the instance where it is not possible to utilise a 3-phase supply, the units can be derated to a 1/2 heat setting for operation via a 230V~ 1P&N 50Hz supply.

Procedure

1. Remove the outlet grille assemblies and, where necessary, the bottom panel and inlet grille to gain access to the element banks and terminal blocks as shown in figure 1 below.




Figure 1.

- 2. Remove the 1st Half Heat (H1) star connection link cable from both sides of each element bank (Figure 2. shows the (bottom red (H1)) star connection link cable replaced with the supplied neutral star connection link cable.
- 3. Fix the push on clips (two on either side) to the inside of the pressure plate as shown in figure1 (the supplied push on clips are a press fit into their fixing holes (Ø3.5mm)). Proceed to

attach the neutral star link connection cable to the push on clips using the tie wraps as shown in figure 3 below.





Figure 2.

Note: Due to extra cable length (for CAB15E) it is necessary to loop the slack cable in the pressure plate and secure it using a supplied tie wrap as shown in figure 1.



- 4. Connect the brass ferrule end of the neutral link cable into the N of the terminal block (along with the Neutral of the single phase supply as shown in figure 4
- 5. Also shown in figure 4 is the supplied (brown) Live link cable, this should be linked from L1 (with connection of Live from single phase supply) to L2 &

Figure 3.

The earth cable is connected as normal within the terminal block (ensure the supply cable is fixed appropriately within the back panel using the correct sized gland).





Figure 4.

6. Check all switch settings operate, as stated within the evaluation table (below). Note H2 should still be connected (as per remote switch connection instruction manual) even though it will not be utilised (this still allows a 1/2 heat setting when switched to full heat rather than no heat at all).



Once the above loadings and switch settings have been confirmed as acceptable, proceed to replace the grille assemblies and, where necessary, the bottom panel.

For reference purposes a full wiring schematic is detailed above.

Single Phase Settings Table		CAB10E	CAB15E	DAB10E
Heat/Fan setting	Heat/Fan result	L1 Amps	L1 Amps	L1 Amps
Half heat - Half fan	Half heat - Half fan	19.8	27.9	27
Full heat - Half fan	Half heat - Half fan	20	29.9	27.8
Half heat - Full fan	Half heat - Full fan	20	29.9	27.8
Full heat - Full fan	Half heat - Full fan	20	29.9	27.8

Please retain your receipt as proof of purchase.



This product complies with European Safety Standard EN 60335-2-30, and European Standards EN 55014, EN 60555-2 and EN60555-3 for Electromagnetic Compatibility. These cover the essential requirements of the EEC Directives 2006/95/EC and 2004/108/EC.

≫Dimplex

© Dimplex UK Limited All rights reserved. Material contained in this publication may not be reproduced in whole or part, without prior permission in writing from Dimplex UK Limited. Dimplex UK Ltd. Millbrook House Grange Drive Hedge End Southampton Hampshire. SO30 2DF

UK Customer Help Line:

Tel: 0845 600 5111

Web-site:

www.dimplex.co.uk

Republic of Ireland:

Tel: 01 842 4833